## FDF Foam Pump Controllers Features

FDF100 Diesel Engine Foam Pump Controllers



## **Product Description**

The FDF Series of Foam Pump Controllers are designed for use with foam concentrate injection, foam transfer and water mist systems for special hazard, aircraft hangar, petrochemical and flammable liquid applications.

All available models meet specific criteria and meet or exceed all North American and International standards including UL 218. Models include Across-the-Line, Diesel Engine and Limited Service foam pump controllers.

#### **Product Features**

#### **Microprocessor Control**

EATON Cutler-Hammer FDF100 Diesel Engine Foam Pump Controllers are microprocessor based. All events surrounding the operation of the controller are stored within the memory, thus giving the ability to diagnose and troubleshoot problems based on an actual history of events. Events are time and date stamped.

A main display unit provides a read-out of parameters such as current pressure, volts and amps and will display error messages as well as provide alarm indication. A status report is available which can be printed locally. The status reports provide a printed record of the current state of the controller.

#### Pressure Transducer: 0 - 600 psi

Each FDF100 controller is equipped with a stainless steel, 0-600 psi pressure transducer capable of withstanding a momentary surge pressure of 1000 psi.

### **Alarm Relay Ratings**

All alarm relays are rated at 10 Amps, 220VAC 1/3HP resistive load only.

#### "Dump Valve" Option

A "dump valve" option is available on FDF100 controllers which allows the diesel engine to consistently start positive displacement foam pumps.

#### Printer / Recorder

The industrial grade thermal printer is housed in a rugged steel enclosure within the controller. The on/off switch, feed and reset buttons are front accessible. A bi-color status LED is also visible on the front of the printer. Green indicates - "Printer Operational" while yellow indicates - "Out of Paper".



Supplied as standard on FDF30 and FDF100 controllers.
Optional for FDF20 controllers.

#### Last 1024 Messages

The internal microprocessor stores the most recent 1024 messages in it's memory. The messages can be printed, or downloaded to a computer. Each message is time and date stamped. The microprocessor acts as a paperless chart recorder.



#### **Common Alarm Relay**

The FDF100 controller has a common alarm relay which energizes whenever there are any alarm conditions present. This relay is deenergized under normal conditions and has LED status indication.

## **Additional Output Relays**

The FDF100 has additional output relays labeled Future #1 and Future #2. The Future #1 relay is factory set for Interlock and cannot be changed by the user. The Future #2 relay is factory set to energize when a signal indicating Low Foam Level, is received. This setting cannot be changed by the user.

#### **Engine Crank Cycle**

Upon detecting a drop in system pressure, the microprocessor sends a start signal to the engine, initiating its' crank cycle.

The crank cycle consists of six periods of 15 second duration, separated by five rest periods of 15 second duration alternating on each set of batteries. If the engine does not start within this cycle, an audible and visible "Fail to Start" alarm is activated. Should voltage of either battery fall below 67% of normal during the crank cycle, a "Battery Failure" alarm will be activated and the FDF100 will alter the cranking sequence by continuing the process with the remaining "good" battery.

The crank cycle terminates when the engine starts. The FDF100 continues to monitor the batteries and engine for conditions such as: water temperature, oil pressure and speed (RPM).

#### **NEMA 2 Enclosures**

All FDF100 controllers come standard with NEMA 2 enclosures unless otherwise ordered. Available options include: NEMA 3R, 4, 4X, 12.

#### **AC Power Failure**

The FDF100 will automatically start upon the loss of AC power. There will be a non-adjustable delay of 180 seconds before the AC failure is detected. If 'disabled', AC power failure will have no effect on the starting of the engine.

#### **Relay Board**

The FDF100 Relay Board is clearly labeled with pull-apart terminal blocks for ease of wiring and connections. All relays are labeled with full description as well as corresponding three letter designation as indicated on the wiring diagram.



A visual LED indicates the energized state of the relav.

All plug-in relays are identical 3PDT, allowing complete interchangeabilty.

All terminal numbers are indicated on both the stationary and moveable portion of the terminal blocks.

Pump Room Trouble and Engine Trouble common alarm relays are standard.

#### **Sequential Start Timer**

The sequential start timer is used to program a start delay after an automatic start request. This function is used for staging the start of pumps in a multiple pump application and also in Diesel backup applications.

FDF100 Diesel Engine Foam Pump Controllers

#### **Product Features**

#### **Alarm & Status Indication**

The display panel is equipped with sixteen indication LED's which indicate various functions and operations of the controller. They are colour keyed to the urgency of the indication. Green indicates normal running conditions, Yellow indicates supervisory alarms and Red indicates critical alarms.

#### **LCD Display / Function Panel**

The 2 line liquid crystal display allows viewing of all programming parameters in addition to battery and pressure information. Messages can also be downloaded to a laptop computer via the communications port located on the top of the main microprocessor board.

#### **Low Foam Level Indication**

When an input from an external pressure switch is received, the LCD display indicates Low Foam Level and a DPDT relay provides an output signal.



#### Alarm LED's

Auto Mode
Fail to Start
Low Oil Pressure
Engine Overspeed
Engine Run
Battery Failure
Charger Failure
Low Fuel Level
High Fuel Level
Fuel Spill
High Engine Temperature
Low Pump Room Temperature
High Reservoir Level
Low Reservoir Level

## **Technical Data and Specifications**

## **Line Terminals (Incoming Cables)**

Recommended Wire Size	Terminal Number	Distance
Stranded # 14	1-5, 9, 10, 16-38, L, N	N. A.
Stranded # 14	39 - 134	N. A.
Stranded # 10	6, 7, 8, 11	0 feet to 25 feet (7.62m)
Stranded # 8	6, 7, 8, 11	25 feet to 50 feet (7.62 - 15.24m)

#### **Standards & Certification**

The FDF100 Diesel Engine Foam Pump Controllers meet or exceed the requirements of Underwriters Laboratories, Underwriters Laboratories Canada, Factory Mutual, the Canadian Standards Association, New York City building code, CE mark requirements and are built to NFPA 20 standards.














## FDF100 Diesel Engine Foam Pump Controllers


**LMR** Electric Fire Pump Controllers

#### **Dimensions**

## FDF100 Diesel - Standard Enclosure - Type NEMA 2, 3R, 12

**Features** 





250 (113)

- 1. All Enclosures finished in Fire Pump red.
- 2. Cable Entrance bottom only.
- 3. Standard Enclosure type NEMA 2, 3R, 12
- 4. Enclosure made from #14 Gauge (0.75) HR Steel.

Dimensions in Inches and (Millimeters).














FDF100 Diesel Engine Foam Pump Controllers


## **Electrical Wiring Schematic** FDF100 Diesel

1-4




#### **FDF100 Diesel Engine Foam Pump Controllers**

# Field Connections Main Terminal Block



## **Relay Card Terminal Blocks**




FDF100 Diesel Engine Foam Pump Controllers

#### April 2004

## **Catalog Number Selection**

## FDF100 Diesel Foam Pump Controller Catalog Numbering System



		Options
C4	-	Remote Contacts (2 Form C) Low Reservoir
C5	-	Remote Contacts (2 Form C) High Reservoir
C6	-	Remote Contacts (2 Form C) Low Fuel
C7	-	Remote Contacts (2 Form C) High Fuel
C8	-	Remote Contacts (2 Form C) Fuel Spill
DV1	-	Dump Valve - DC Voltage output
DV2	-	Dump Valve - 120V output
DV3	-	Dump Valve - 220V output
E1	-	NEMA 3R - Raintight Enclosure
E2	-	NEMA 4 - Watertight Enclosure
E3	-	NEMA 12 - Dust Tight Enclosure
E5	-	NEMA 4X - 304 Stainless Steel
E8	-	Tropicalization
E9	-	NEMA 4X - Painted Steel
E10	-	NEMA 4X - 316 Stainless Steel
EΧ	-	Export Crating
F	-	Floor Stand
F2	-	Floor Stand - 2 Inch Height
LO	-	Powered Louver Contacts
P5	-	Proof Pressure Switch - ALCO 15-290 PSI
P8	-	Shutdown (Requires P7 Option)
P10	-	Pressure Transducer - Sea Water
P13	-	Externally Mounted Pressure Transducer
R1	-	Space Heater (120 / 220V)
R2	-	Space Heater c/w Thermostat
R3	-	Space Heater c/w Humidistat
R4	-	Low Room Temperature Switch
S1	-	Fuel Level Switch, 16 Inch
S2	-	Fuel Level Switch, 45 Inch
		A

**FDF100 Diesel Engine Foam Pump Controllers** 

### **Product Selection**

FDF100 Diesel Engine Foam Pump Controller Catalog Numbering System

**Catalog Number Selection Chart** 

Catalog Number	Voltage	Price
FDF100-12L-N-A	110 - 120V	\$6,290
FDF100-24L-N-A	50 / 60 HZ	\$6,410
FDF100-12C-N-A		\$6,290
FDF100-24C-N-A		\$6,410
FDF100-12L-N-B	220 - 240V	\$6,290
FDF100-24L-N-B	50 / 60 HZ	\$6,410
FDF100-12C-N-B		\$6,290
FDF100-24C-N-B		\$6,410
FDF100-12L-N-C	460 - 480V	\$6,780
FDF100-24L-N-C	60 HZ	\$6,900
FDF100-12C-N-C		\$6,780
FDF100-24C-N-C		\$6,900

**Catalog Number Selection Chart** 

Catalog Number	Voltage	Price
FDF100-12L-N-D	575 - 600V	\$6,780
FDF100-24L-N-D	60 HZ	\$6,900
FDF100-12C-N-D		\$6,780
FDF100-24C-N-D		\$6,900
FDF100-12L-N-E	380 - 415V	\$6,890
FDF100-24L-N-E	50 / 60 HZ	\$7,010
FDF100-12C-N-E		\$6,890
FDF100-24C-N-E		\$7,010

## **Options**

**Catalog Number Option Selection - FDF100** 

Designation	Description	Price
		•
C4	Remote Contacts (2 Form C) Low Reservoir	\$75
C5	Remote Contacts (2 Form C) High Reservoir	\$75
C6	Audible & Visible Alarm - Low Fuel	\$75
C7	Audible & Visible Alarm - High Fuel	\$75
C8	Audible & Visible Alarm - Fuel Spill	\$75
DV1	Dump Valve - DC Voltage output	N/C
DV2	Dump Valve - 120V output	\$220
DV3	Dump Valve - 220V output	\$220
E1	NEMA 3R - Raintight Enclosure	\$380
E2	NEMA 4 - Watertight Enclosure	\$700
E3	NEMA 12 - Dust Tight Enclosure	\$25
E5	NEMA 4X - 304 Stainless Steel	\$1900
E8	Tropicalization	\$275
E9	NEMA 4X - Painted Steel	\$1400
E10	NEMA 4X - 316 Stainless Steel	\$3000
EX	Export Crating	\$525
F	Floor Stand	N/C
F2	Floor Stand - 2 Inch Height	\$25
P5	Proof Pressure Switch - ALCO 15-290 PSI	\$120
R1	Space Heater (120 / 220V)	\$185
R2	Space Heater c/w Thermostat	\$250
R3	Space Heater c/w Humidistat	\$250
R4	Low Room Temperature Switch	\$145
S1	Fuel Level Switch, 16 Inch	\$180
S2	Fuel Level Switch, 45 Inch	\$200
+	Additional Alarm Relays (Each)	\$75

## FDF Foam Pump Controllers Features

April 2004

#### FDF20 Limited Service / FDF30 Across-the-Line Foam Pump Controllers



### **Product Description**

The FDF Series of Foam Pump Controllers are designed for use with foam concentrate injection, foam transfer and water mist systems for special hazard, aircraft hangar, petrochemical and flammable liquid applications.

All available models meet specific criteria and meet or exceed all North American and International standards including UL 218. Models include Across-the-Line, Diesel Engine and Limited Service foam pump controllers.

#### **Product Features**

#### **Microprocessor Control**

EATON Cutler-Hammer FDF Foam Pump Controllers are microprocessor based. All events surrounding the operation of the controller are stored within the memory, thus giving the ability to diagnose and troubleshoot problems based on an actual history of events. Events are time and date stamped.

A main display unit provides a read-out of parameters such as current pressure, volts and amps and will display error messages as well as provide alarm indication. A status report is available which can be printed locally. The status reports provide a printed record of the current state of the controller.

#### Alarm & Status Indication

The display panel is equipped with nine red Alarm LED's and nine green Status LED's which indicate various functions and operations of the controller. The membrane keypad has curved dome windows which allow viewing from a wide angle.

#### **LCD Message Retrieval**

The 2 line liquid crystal display allows viewing of messages and event information without opening the front door of the controller. Messages can also be downloaded to a laptop computer via the communications port located on the top of the main microprocessor board.

#### Printer / Recorder

The industrial grade thermal printer is housed in a rugged steel enclosure within the controller. The on/off switch, feed and reset buttons are front accessible. A bi-color status LED is also visible on the front of the printer. Green indicates - "Printer Operational" while yellow indicates - "Out of Paper".



Supplied as standard on FDF30 and FDF100 controllers.
Optional for FDF20 controllers.

#### Last 2048 Messages

The internal microprocessor stores the most recent 2048 messages in it's memory. The messages can be printed, viewed on the LCD screen or downloaded to a laptop. Each message is time and date stamped. The LCD display acts as a paperless chart recorder.



#### **Elapsed Time Meter**

The LMR monitors and records the run time of the motor, in hours, whenever the pump is running. The actual run time can be viewed on the LCD display in 1 hour increments.

#### **Number of Operations Counter**

The LMR controller monitors and records the number of times the pump has started. The actual count can be viewed on the LCD display.

#### **Volts and Amps Display**

The LCD display located on the main display panel, simultaneously indicates the voltage and amps on all three phases of power coming into the controller

#### **Sequential Start Timer**

The sequential start timer is used to program a start delay after an automatic start request. This function is used for staging the start of pumps in a multiple pump application and also in Diesel backup applications.

#### **Weekly Test Timer**

The weekly test timer allows the user to set the controller to automatically start and stop the controller once per week. The number of weeks between tests is set via the front keypad. The weekly test date and time can be viewed on the LCD display.

#### Pressure Transducer: 0 - 600 psi

Each LMR controller is equipped with a stainless steel, 0-600 psi pressure transducer capable of withstanding a momentary surge pressure of 1000 psi.

#### **NEMA 2 Enclosures**

All LMR controllers come standard with NEMA 2 enclosures unless otherwise ordered. Available options include: NEMA 3R, 4, 4X, 12.

#### **NEMA Rated Contactors**

NEMA rated Freedom or A200 Series EATON Cutler-Hammer contactors are used in all LMR fire pump controllers. A wide variety of coil voltages are available for domestic and international use.

#### **Emergency Start Operator**

A mechanically operated emergency start handle activates the motor contactor independent of any electrical control circuits or pressure switch input.



#### Extra Set of Form-C Contacts for Phase Reversal and Phase Failure

The phase reversal and phase failure relays come standard with an extra set of contacts that can be used for remote alarm indication.

#### Standards & Certification

The FDF Foam Pump Controllers meet or exceed the requirements of Underwriters Laboratories, Underwriters Laboratories Canada, Factory Mutual, the Canadian Standards Association, New York City building code, CE mark requirements and are built to NFPA 20 standards.













## **FDF** Foam Pump Controllers **Features**

FDF20 Limited Service / FDF30 Across-the-Line Foam Pump Controllers

#### **Product Features**

### **Common Alarm Relay and Contacts**

The LMR controller has a common alarm relay which de-energizes whenever there are any alarm conditions present. This relay is energized under normal conditions and has LED status indication on the main relay board.

#### Low Foam Level Indication

Low foam concentrate level is indicated by an LED on the display membrane labelled Low Foam Level. It indicates when the controller receives a signal from an external switch and a DPDT relay provides an output signal.

#### Status & Alarm Indication



#### Status LED's

Power On Pump Running **RPT** Timer Sequence Timer Local Start Remote Start Deluge Valve Interlock On Low Pressure

#### Alarm LED's

Phase Reversal Phase Failure Fail To Start Undervoltage Overvoltage Relief Valve Discharge Locked Rotor Trip Low Foam Level **Emergency Start** 

## **Technical Data and Specifications**

Line Terminals (Incoming Cables) - FDF20

	Line Terminals on Main Isolation Switch (Incoming Cables)								
	LINE VOLTAGE					Qty. & Cable Sizes	Service Entrance GND.LUG		
	200 - 208	220 - 240	380 - 415	440 - 480	550 - 600		Qty. & Cable Sizes		
Max. Hp	30	30	30	30	30	(1)#14-1/0 PER Ø (CU/AL)	(1)#14-3/0 (CU/AL)		

#### Load Terminals (To Motor) - FDF20

	Load Terminals (To Motor)									
	LINE VOLTA	(GE	Qty. & Cable Sizes							
	200 - 208	220 - 240	380 - 415	440 - 480	550 - 600					
Мах. Нр	10	15	25	25	25	(1)#14-#3 PER Ø(CU/AL)				
	25	30	30	30	30	(1)#14-1/0 PER Ø (CU/AL)				
	30					(1)#6-250MCM Ø (CU/AL)				

#### Line Terminals (Incoming Cables) - FDF30

Line Terminals on Main Isolation Switch (Incoming Cables)								
	LINE VOLTAG	SE .			Qty. & Cable Sizes	Service Entrance GND.LUG		
	200 - 208	220 - 240	380 - 415	440 - 480	550 - 600		Qty. & Cable Sizes	
Мах. Нр	30	30	60	75	100	(1)#14-1/0 PER Ø (CU/AL)	(1)#14-2/0 (CU/AL)	
	40	40	100	100	-	(1)#4-4/0 PER Ø (CU/AL)	(1)#14-2/0 (CU/AL)	

<sup>\*</sup> Available Coils: 380V-50Hz, 380V-60Hz, 415V-50Hz, 415V-60Hz

### Load Terminals (To Motor) - FDF30


	Load Terminals (To Motor)								
	LINE VOLTA	Qty. & Cable Sizes							
	200 - 208	220 - 240	380 - 415	440 - 480	550 - 600				
Мах. Нр	10	15	25	25	25	(1)#14-#3 PER Ø(CU/AL)			
	25	30	50	50	50	(1)#14-1/0 PER Ø (CU/AL)			
	40	50	75	100	100	(1)#6-250MCM Ø (CU/AL)			

For Proper Cable Size Refer to National Electrical Code NFPA-70

**FDF20 Limited Service Foam Pump Controllers** 

#### **Dimensions**

## FDF20 Limited Service - Standard Enclosure - Type NEMA 2, 3R, 4, 4X, 12



Motor Hp	Line Voltage	Withstand Rating	Withstand Rating			
		Standard	Intermediate	Lbs. (Kg)		
5 - 30	200 - 208V	25,000	65,000	305		
5 - 30	220 - 240V			(138)		
5 - 30	380 - 415V *					
5 - 30	440 - 480V					
5 - 30	550 - 600V	18,000	25,000			
5 - 15	230V - S/P	10,000	65,000			

<sup>\*</sup> Available Coils: 380V-50Hz, 380V-60Hz, 415V-50Hz, 415V-60Hz














- 1. All enclosures finished in FirePump red.
- 2. Cable Entrance either top or bottom.
- 3. Standard Enclosure type NEMA 2.

**FDF** Foam Pump Controllers

**Features** 

# Electrical Wiring Schematic FDF20 Limited Service




FDF30 Across-the-Line Foam Pump Controllers

#### **Dimensions**

1-12

## FDF30 Across-the-Line - Standard Enclosure - Type NEMA 2, 3R, 4, 4X, 12



Motor Hp	Line Voltage	Withstand Rating			Approx. Weight
		Standard	Intermediate	High	Lbs. (Kg)
5 - 40	200 - 208V	100,000	150,000	200,000	305
5 - 50	220 - 240V				(138)
5 - 75	380 - 415V *				
5 - 100	440 - 480V				
5 - 100	550 - 600V	25,000	100,000		

<sup>\*</sup> Available Coils: 380V-50Hz, 380V-60Hz, 415V-50Hz, 415V-60Hz














#### NOTES:

- 1. All enclosures finished in FirePump red.
- 2. Cable Entrance either top or bottom.
- 3. Standard Enclosure type NEMA 2.

FDF30 Across-the-Line Foam Pump Controllers

#### **Dimensions**

## FDF30 Across the Line - Standard Enclosure - Type NEMA 2, 3R, 4, 4X, 12



	Line	Withstand Rating		Approx.	Α	В	С	D	
	Voltage	Standard	Intermediate	High	Weight Lbs. (Kg)				
50 - 100	200 - 208V	100,000	Consult	Consult	565	47.85	37.23	11.00	27.10
60 - 125	220 - 240V		Factory	Factory	(256)	(1215)	(946)	(279)	(688)
100 - 200	380 - 415V *								
125 - 250	440 - 480V								
125 - 300	550 - 600V	25,000	35,000						
125 - 150	200 - 208V	100,000	100,000 Consult Factory		660	53.85	43.23	21.74	33.10
150 - 200	220 - 240V				(299)	(1368)	(1098)	(552)	(841)
250 - 300	380 - 415V *								
300 - 400	440 - 480V								
350 - 400	550 - 600V	25,000	35,000						

<sup>\*</sup> Available Coils: 380V-50Hz, 380V-60Hz, 415V-50Hz, 415V-60Hz














#### NOTES:

- 1. All enclosures finished in FirePump red.
- 2. Cable Entrance either top or bottom.
- 3. Standard Enclosure type NEMA 2.

FDF30 Across-the-Line Foam Pump Controllers


# Electrical Wiring Schematic FDF30 Across the Line

1-14




## **Options - Wiring Diagram**


## FDF20 Limited Service / FDF30 Across-the-Line



### Main Terminal Block: TB1



## **Typical Controller Connection**



- 1. Terminal 49 is common to all dry contact inputs. DO NOT APPLY A VOLTAGE ON THESE TERMINALS 2. Contacts shown in de-energized state (Fail Safe).
- Relay Card

START UP		PHASE FAILURE		COMMON ALARM		ACCELERATION		PHASE REVERSAL		INTERLOCK ON		LRP
1CR		2CR		3CR		4CR		5CR		6CR		7CR
d/H	r#Hh	r#Hh	r# <del> </del>  h	r#Hh	гЖН	гИН	rHHh	rHHH	r#Hh	r#Hh	rlf-lh	r#HH
9 60 61	62 63 64	65 66 67	68 69 70	71 72 73	74 75 76	77 78 7	9 80 81 82	83 84 85	86 87 88	89 90 91	92 93 94	95 96 9
	$\top$	$\top$	$\top$	$\top$	$\top \top \top$	$\top$		$\top$	$\top$	$\top$		$\top$
<b>/</b>	<b>~~~</b>			<b>~~~</b>	<b>~~~</b>	<b>~~</b>		<b>~~~</b>	<b>~~~</b>	<b>~~~</b>		$\checkmark$
1	2	35	25	35	25	1	2	3	2	3	2	4
(1)	(2)	(3)(5)	(2)(5)	(3)(5)	(2)(5)	(1)	(2)	(3)	(2)	(3)	(2)	(-

#### NOTES:

- 1. To Control Circuit
- 2. Spare for Customer Connections
- 3. To TB1
- 4. To Shunt Trip
- 5. Contacts Shown in De-Energized State (Fail Safe)

FDF20 Limited Service / FDF30 Across-the-Line Foam Pump Controllers

April 2004

## **Catalog Number Selection**

## FDF20 Limited Service / FDF30 Across-the-Line Foam Pump Controller Catalog Numbering System

